

No More Air Loss or Water Leaks Around Your Windows and Doors



+



=



S
A
V
I
N
G
S

Log Gap Cap

Pre-cut foam inserts

Energy Seal

Log home sealant



How to Seal Step-by-Step:

1. Use masking tape around the window or door seam.

2. Insert Log Gap Cap into the crevice using trowel. Log Gap Cap provides an even surface for sealant application and makes it easier to apply a uniform thickness across the gap.

3. Apply Energy Seal™ and tool smooth.

4. Remove masking tape as soon as tooling is complete.



For more information call us

PERMA-CHINK
SYSTEMS, INC.

1-800-548-3554
or visit www.permachink.com