



Rev 6/11

Clear Log End Sealant

Log End Seal is designed to protect exposed log ends from deterioration due to the elements. Sunlight, wind, rain, snow, and ice all play a role in degrading wood surfaces. This is especially true for log ends where the end grain is exposed and cracks and checks are prone to develop. Even if the ends are coated with a quality stain, the exposed end grain of the wood acts like small straws drawing water into the log. This gives rot and decay an opportunity to start. If left unprotected, log or log corner replacement may eventually be required.



Contents: 1 Gallon (approx. 3.7 liters)

www.permachink.com

Log End Seal is a clear finish that prevents water from penetrating into log ends thus providing a layer of protection against sun, wind, and weather damage.

APPLICATION STEPS

1. Thoroughly sand all exposed log ends, taking care not to leave heavy sanding marks or gouges.
2. Apply any LIFELINE™ brand exterior stain to the entire home, including the log ends.
3. When the LIFELINE stain has dried, apply Log End Seal with a brush, pad or trowel taking care to completely cover the exposed log end. Try to avoid leaving brush marks or uncoated areas on the ends. Wipe off any excess that may have worked its way onto the sides of the logs.
4. Allow the Log End Seal to dry and finish with a Lifeline topcoat over the entire home.

Clean-Up

Wash equipment and brushes with soap and warm water. Dried Log End Seal may be removed with alcohol.

**CAUTION - DO NOT TAKE INTERNALLY
DO NOT ALLOW TO FREEZE**

**PERMA-CHINK
SYSTEMS, INC.**

www.permachink.com

Eastern Division
Western Division
Colorado
Montana
Minnesota

1-800-548-3554
1-800-548-1231
1-800-433-8781
1-800-479-7090
1-877-244-6548



MADE IN USA