

Technical Tip

Osborn Buffing Brushes

Osborn Buffing Brushes are excellent tools to help prepare a surface before the first coat of finish is applied. They consist of nylon bristles impregnated with particles of silicon carbide which act as an abrasive. However, as their name implies, they are buffing brushes not sanding brushes. So what's the difference? Sandpaper and sanding disks are designed to remove the top layer of wood whereas Osborn Buffing Brushes are designed to smooth the surface of the wood without removing the entire top layer.

Osborn Brushes require a buffer or polisher with 5/8 x 11 National Coarse (NC) threads. Although a constant speed buffer of around 1800 RPM will work, one with a variable speed is much easier to use and will do a better job.

So what are some applications for the use of Osborn Brushes?

1. When the surface has been stripped or pressure washed and you want to remove any feathering that may have occurred.
2. If the grain of the wood has been raised due to contact with water (mostly interior situations).
3. To remove mill glaze on interior and exterior wood surfaces.
4. To even out the texture of hewn surfaces since the flexible bristles reach the hills and valleys.
5. If a home has been blasted the use of an Osborn Brush can help reduce rough texture of the surface.

What are Osborn Brushes not suitable for?

1. To make a blasted surface completely smooth again.
2. To remove a finish.
3. To remove discolorations that are deep within the wood.

Osborn brushes are not an alternative to sandpaper or sanding disks. Sanders and sanding disks consist of rough, flat surfaces and will remove more wood on high spots than in depressions whereas Osborn Brushes pretty well follow the contour of the surface. To correctly use an Osborn brush you never need apply much pressure to the buffer, just hold it in place and let the brush do the work.

We carry four different Osborn Brushes. For logs and log siding, we recommend using the flared 6" diameter brushes since they do a good job and are easy to use. The 4" brushes may be used for small or tight areas. For exterior surfaces 80 grit brushes should always be used. On interior surfaces you can use either 80 or 120 grit brushes.



Tool Required

Buffer or polisher with 5/8x11 National Course (NC) threads. Best speed is around 1800 RPM but variable speed is handy.

Pictured - Makita 9227C Sander - Polisher.

Osborn Buffing Brushes



Cup Brush 4"
80 grit
#32148



Cup Brush 4"
120 grit
#32149



Cup Brush 6"
80 grit
#32132



Cup Brush 6"
120 grit
#32131



Osborn Brush in use



Feathered surface



Same surface after brushing